Rechargeable





User Manual

Thank you for purchasing our product. For optimum performance and safety, please read this instruction carefully before operating the product. Please read this manual for further reference



- . Green LED on indicates unit is warming-up.
- . Green LED off indicates unit stays at 40°C (104°F) . Red LED will flash when the
- unit has less than 15% power capacity.
- Red LED indicates unit is charging.
- Green LED illuminates when unit is fully charged.

SPECIFICATIONS

Power supply:

Built-in battery: Charging time: Battery life: Surface temperature: Size of main body: Base machine mass:

Rechargeable (mini USB port 5V 600mAh) Special Lithium-ion battery 2 hours Unito 3 hours Approx. 40°C (104°F) 90X40X8 (mm)

How to Use

CHARGE THE WARMER

- 1. Charge the warmer with the USB cable from computer or USB socket AC/Car adapter (not included), the charging LED will turn red
- 2. When the charging LED changes to green, it means the charging is finished.

OPERATING THE HAND WARMER

- 1. Press the ON/OFF button. The green LED will illuminates green. After a while, the warming LED will be off,
- 2. This means the temperature reaches 40°C (104°F) and stays at this temperature. When the warming LED is on green again, it means the warmer's temperature is below 40°C (104°F) and starts warming up to reach 40°C (104°F) again.

RFMARK

1. When the warmer is in low power, the warming LED will turn red to remind you that it needs to be recharged. 2. When you would like to turn the hand warmer off, press the ON/OFF button again.

CAUTION

- 1. Please charge the warmer completely before using it for the first time
- 2. Don't drop, disassemble or attempt to repair the warmer by yourself.
- 3. Avoid exposure to water or high humidity
- 4. Don't expose the warmer to any heat source above 50°C (122°F)
- 5. Never attempt to use the hand warmer for purposes other than warming your hands.







Item No: 5200

5560909255200

48a